

MAS-100 ISO DOWNGRADE INSTRUCTION

1. INSTRUCTION ON HOW TO DOWNGRADE A MAS-100 ISO NT WITH FW V2.8.5 TO V2.7

This instruction describes the preparation steps and the procedure to downgrade the Firmware (FW) on a MAS-100 Iso NT with V2.8.5 to V2.7(.0).

Note:

For more information and / or troubleshooting please read the instrument user manual.

1.1. PREPARATION STEPS FOR FIRST USE ONLY

1. Download and install the MAS-100 Iso NT and MH C&C PC Software V3.1.14
2. Download and install the FUT V1.0.5
3. Copy the FW file "MAS100ISONT_ver_2.7.0000_(13).mas100fw" to the "Downloads" directory

1.2. PROCEDURE

1. Start PC SW V3.1.14
2. Create xml report, save as *_before downgrade.xml
3. Close PC SW
4. Start FUT
5. Select FW V2.7.0 to update
6. Start Update, wait until finished and instrument has been restarted
7. Close FUT
8. Power reset the instrument
9. Start PC SW V3.1.14
10. Create xml report, save as *_after downgrade.xml
11. Compare the content in the *_before downgrade.xml with the *_after downgrade.xml in the internet explorer.
12. The content must be the same except the Firmware Version (called SWVersion) and the CheckCode
13. The Downgrade succeeded.